

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>0884010-07</u> Contact, Receiver, Coax, Female, Double-Shield RG178</p>	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/L80	08402-01 08404-01 11604030003 11604032003 12122-01 12122-02 1213206-01 12132160R-01 30100040-01 561302 603002 70101900/C 70107600 803024-01	Crimp: 452300 Hex Die: 452309	412615
<p><u>0884010-08</u> Contact, Receiver, Mini-Coax, Special RG178</p>	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/L80	08402-01 08404-01 11604030003 11604032003 12122-01 12122-02 1213206-01 12132160R-01 30100040-01 561302 603002 70101900/C 70107600 803024-01	Crimp: 452300 Hex Die: 452312	412615
<p><u>0884010-10</u> Contact, Receiver, Coax, Female, RG178 <u>0884010-11</u> Contact, Receiver, Coax, Female, RG316 & RG174,</p>	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/L80	08402-01 08404-01 11604030003 11604032003 12122-01 12122-02 1213206-01 12132160R-01 30100040-01 561302 603002 70101900/C 70107600 803024-01	Crimp: 452300 Hex Die: 452312	412615

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<u>0884010-12</u> Contact, Receiver, Mini-Coax, RG179, 75 Ohm	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/L80	08402-01 08404-01 11604030003 11604032003 12122-01 12122-02 1213206-01 12132160R-01 30100040-01 561302 603002 70101900/C 70107600 803024-01	Crimp: 452300 Hex Die: 452312	412615
<u>0884010-13</u> Contact, Receiver, Coax, Female, JOY-014	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/L80	08402-01 08404-01 11604030003 11604032003 12122-01 12122-02 1213206-01 12132160R-01 30100040-01 561302 603002 70101900/C 70107600 803024-01	Crimp: 452300 Hex Die: 452309	412615
<u>0884011-01</u> Contact, Receiver, Power, Female	S/08 S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/75 S/L80	08403R-01 11604032007 12122-02 1213206-01 12132160R-01 30100040-01 561301 561314 603001R-01 603014 70101900/P 70107600/P 701142800R 753014 8031628R-01	Solder Termination	412615

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>0884012R-01</u> Contact, Receiver, Signal, 20-24 AWG</p> <p><u>0884013R-01</u> Contact, Receiver, Signal / Hi-Density Power, 14 AWG max.</p>	<p>S/08</p> <p>S/120</p> <p>SCOUT</p> <p>S/60, L2000</p> <p>S/64</p> <p>S/75</p> <p>S/L80</p>	<p>08401R-03</p> <p>08403R-01</p> <p>12121R-01</p> <p>12126R-01</p> <p>12132160R-01</p> <p>561301</p> <p>561311</p> <p>603001R-01</p> <p>603011R-01</p> <p>70106400R-01</p> <p>70109600R-01</p> <p>701142800R</p> <p>70125600R-01</p> <p>70132000R-01</p> <p>753009R-02</p> <p>753025R-01</p> <p>8031628R-01</p>	<p>Crimp: 452400</p> <p>Positioner: 452401</p>	<p>412604</p>
<p><u>0884022R-01</u> Contact, Receiver, Signal, 5 Amp, 0.025" ww post</p>	<p>S/08</p> <p>SCOUT</p> <p>S/60, L2000</p> <p>S/64</p> <p>S/75</p> <p>S/L80</p>	<p>08401R-03</p> <p>08403R-01</p> <p>561301</p> <p>561311</p> <p>603001R-01</p> <p>603011R-01</p> <p>70106400R-01</p> <p>70109600R-01</p> <p>701142800R</p> <p>70125600R-01</p> <p>70132000R-01</p> <p>753025R-01</p> <p>8031628R-01</p>	<p>N/A</p>	<p>412604</p>
<p><u>0884027R-01</u> Contact, Signal., right-angle (PCB)</p> <p><u>0884027R-02</u> Contact, Signal., right-angle (PCB)</p> <p><u>0884027R-03</u> Contact, Signal., right-angle (PCB)</p>	<p>S/08</p> <p>S/75</p>	<p>08401R-02</p> <p>753025R-01</p> <p>753025R-02</p>	<p>N/A</p>	<p>412604</p>

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>0884027R-04</u> Contact, Receiver, Signal, Short PCB post,</p> <p><u>0884027R-05</u> Contact, Receiver, Signal, Med. PCB post</p> <p><u>0884027R-06</u> Contact, Receiver, Signal, Long PCB post,</p>	S/64 SCOUT	70109600R-01 561304	N/A	412604
<p><u>0884028-01</u> Contact, Receiver, Mini Coax, Short PCB post</p> <p><u>0884028-02</u> Contact, Receiver, Mini Coax, Long PCB post</p>	S/08	08402-01	N/A	412615
<p><u>40-120001-01</u> Contact, Receiver, Micro Coax, RG178, JOY 018 * NEW</p> <p><u>40-120001-02</u> Contact, Receiver, Micro Coax, JOY 014</p> <p><u>40-120001-03</u> Contact, Receiver, Micro Coax, JOY 05</p>	CTI	40-110591-01 (59 Pos) 40-111521-01 (152 Pos.)	Crimp: 452300 Hex Die: 452315 Center Conductor Sizing Tool: 412649 * NEW Outer Conductor Sizing Tool: 412648 * NEW	412639
<p><u>40-120003-01</u> Contact, Receiver, Power 14 AWG Max.</p>	CTI	40-110593-01 (59 Pos) 40-111523-01 (152 Pos.)	Crimp: 452200 Hex Die: 452221	412647
<p><u>7400400-2</u> Snap-Lock Taper Pin, 22-26 AWG</p> <p><u>7400400-3</u> Snap-Lock Taper Pin, 16-20 AWG</p>	S/06	06302 06303	Crimp: 452200 Positioner: 452202	412603
<p><u>7847211-40-L</u> Contact, Coax, Female, 50 Ohm, Long PCB pins</p> <p><u>7847211-40-S</u> Contact, Coax, Female., 50 Ohm, Short PCB pins</p>	S/06	06304	N/A	412601

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>7847211-30</u> Contact, Recvr. Coaxial, Female, 95 Ohms, accepts RG180 and RG179</p> <p><u>7847211-40</u> Contact, Recvr., Coaxial, Female, 50 Ohms, accepts RG316 and RG174</p>	S/06 S/1160 S/120 S/64 S/75	06304 11603015001 12109-01 12109-02 12112-01 70101200/C 701050600 753003	Crimp: 452200, 452300 Hex Die: 452301 Positioner: 452205	412601
<p><u>7850211</u> Contact, Receiver, Power, Male, 30 Amps, accepts 12-16 AWG</p> <p><u>880127</u> Contact, Power, Male, 50 Amps, Solder, 8 Awg (max.)</p>	S/06 S/1160 S/120 S/64 S/75	06305 11603015001 12107-01 12109-01 12109-02 12112-02 70101200/P 753004 753008 753009 753009R-02	Solder Termination	412601
<p><u>7861200-11</u> Contact, Receiver, Mini-Coax, 50 Ohm, RG316 & RG174</p> <p><u>7861200-10</u> Contact, Mini-Coax, Female., RG178 cable, 50 Ohm</p>	S/75, ARINC	753013	Crimp: 452300 Hex Die: 452312 Positioner: 452206	412615
<p><u>7864100</u> Contact, Twinax / Triax, * Specify Cable Type</p>	S/120 SCOUT S/60, L2000 S/64 S75, ARINC	12124-01 561318 603018 70100600 753019	Crimp: 452300 Hex Die: 452306, 452307 Positioner: 452211	

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>7865100</u> Contact, Receiver, High-Freq. Coax, DC-3 GHz., Crimp</p> <p><u>7865100-02</u> Contact, Receiver, High-Freq. Coax, DC-4 GHz., SMB Type</p> <p><u>7865100-04</u> Contact, Receiver, High-Freq. Coax, DC-20 GHz., RG142</p>	<p>S/1160 S/120 MPX SCOUT S/60, L2000 S/64 S/75 S/L80</p>	<p>11604024005 12123-01 30120230-01 561308 603008 70102500 753022 753024 803018-01</p>	<p>Crimp: 452300 Hex Die: 452303 Hex Die: 452308 (-04 only)</p>	412615
<p><u>7865100-03</u> Contact, Receiver, High-Freq. Coax, 75 Ohm, 2 GHz</p>	<p>S/1160 S/120 SCOUT S/60, L2000 S64 S/75 S/L80</p>	<p>11604024005 12123-01 561324 603024 70102500 753022 753024 803018-01</p>	<p>Crimp: 452200/M, 452300 Hex Die: 452301 Positioner: 452212</p>	412615
<p><u>7865100-05</u> Contact, Receiver, High-Freq. Coax, DC-26 GHz., SMA Type</p>	<p>S/1160 S/120 SCOUT S/60, L2000 S64 S/75 S/L80</p>	<p>11604024005 12123-01 561308 603008 70102500 753022 753024 803018-01</p>	<p>Crimp: 452300 Hex Die: 452308</p>	412615
<p><u>7865100-08</u> Contact, Hi-Freq. Coax, DC-40GHz.,</p>	<p>S/120 SCOUT S/60, L2000 S/64 S/75</p>	<p>12128-01 12128-02 561312 603012 701050600 753029</p>	2.92 MM Interface	412633
<p><u>F01P025</u> Receiver Power Contact, 12 AWG Max.</p>	MPX	<p>30100052-01 30120230-01 30125230-01</p>	<p>Crimp: 452200/3 * Positioner: 452216 * * Used only on 12AWG wire applications. Otherwise, contact has solder termination.</p>	412635

Receiver Contacts Cross-Reference List

CONTACT / DESCRIPTION	USED IN:		CRIMPING TOOL	EXTR. TOOL
	SERIES	MODULES		
<p><u>F01S006</u> Receiver Signal Contact, 22-26 AWG</p> <p><u>F01S006-02</u> Receiver Signal Contact, 18-20 AWG</p>	S/120 MPX	121600-01 30100390-01 30120230-01 30125230-01	Crimp: 452200/M Positioner: 452215	412634
<p><u>F01S006-03</u> Receiver Signal Contact, W/W Post</p>	S/120 MPX	121600-01 30100390-01 30120230-01 30125230-01	N/A	412634
<p><u>HST-153-9</u> Contact, Power Socket, 3mm, Crimp/solder, up to 12 AWG wire</p>	ARINC	753051G 753051G-01 753053G	Solder Termination	412614
<p><u>HST202/5</u> Contact, Receiver, Signal Socket, 1mm, Crimp/solder, 20-24 AWG wire</p>	S/ROTARY S/120 ARINC	10921-01 12111-01 12111-02 753051G 753051G-01 753052	Crimp: 452200 Positioner: 452206	412613
<p><u>HST-240-9</u> Contact, Signal Socket, 1mm, 1st row, PCB</p> <p><u>HST-241-9</u> Contact, Signal Socket, 1mm, 2nd row, PCB</p> <p><u>HST-242-9</u> Contact, Signal Socket, 1mm, 2nd row, PCB</p>	ARINC	753050G 753050G-01 753053G		412613