REV A IN 7850211



Wiring Assembly Instructions

7850211 - Contact, Receiver - Power, 30 Amp, 12 Awg Max, Solder.



Fig. A. (Contact Sub-Assembly)

Contact Crimp Information Table								
Wire	Wire	Strip Length In	Crimp Tool	Hex Die Set/	Indicator	Selector	Heat-shrink	
Type	Awg.	Inches		Positioner		No.	Length X Dia.	
Stranded	16	A)1/2"	N/A	N/A	N/A	N/A	3/16 X 5/8	
	14	A)1/2"						
	12	A)1/2"						

Pull Test Values				
16 Awg	39lbs			
14 Awg	48lbs			
12 Awg	62lbs			



(Values based on M22759/11xx)

(Example of Equipment)

NOTE 1: Refer to **IPC/WHMA-A-620A** standard (Ch. 11.1.2) for cable lengths, measurements and tolerance.

NOTE 2: Overall length of cable should be less 3/8" to compensate for the contact attachment.

STEP 1) Strip wire to dimensions in "Contact Crimp Information" Table using a ruler along with a wire stripper as shown in **Fig. B.**



Fig. B.

STEP 2) Tin stripped wire. (This prevents wire strands from fraying) as in Fig. C.



Fig. C.

REV A IN 7850211

STEP 3) Put contact in a fixture, insert wire in contact and solder per **IPC/WHMA-A-620A** standard (Ch. 4.9.6) for Solder Connections – Cup Terminals.

NOTE: Inspect after insertion of wire into contact to make sure no strands of wire is protruding outside the Cup of the contact.

STEP 4) Remove and inspect Contact, making sure there is no spillage of solder over it and meets all standards set in **IPC/WHMA-A-620A** standards. **Fig. D.**



STEP 5) Slide Heat-Shrink over completed Assembly for Strain Relief, Fig. E below.



NOTE: Shrink-tube is to provide strain-relief and exposed solder joint.